



LOTUS ARM RESTS

INSTALLATION INSTRUCTIONS

These self-adhesive EVA foam arm rests add just enough cushion for those longer drives and road trips, but are unobtrusive enough to not get in the way.

Tools & Supplies needed:

- Tape measure/ruler
- Masking tape

Install as follows:

1. First step is to clean the door sill. The arm rests will mount at the narrow /door latch end of the sills, within the first 14" or so. Thoroughly clean the surface with the alcohol wipes provided:



2. **IMPORTANT!** Determine the exact placement of the arm rest from INSIDE the car with the door closed. The logo should face the outside of the car, and the small end of the arm rest should end up about 3-1/4 – 3-1/2" from the end of the sill, and pushed flush with the door panel. *Ensure the entire arm rest lies on the flat portion of the sill (do not try to wrap over the edge):*



3. Mark the placement with masking tape once happy with the positioning:



4. Peel back the first couple inches of backing material, line up the placement with the tape, and gently press into place. The arm rest is hard to reposition once stuck, but you should be able to peel back and position if needed, then slowly peel back the rest of the backing and press fully into place. Press firmly over the entire surface of the arm rest and hold for about 30 seconds. Repeat for the other side and that's it!



Please use your best judgement with all of the above, and let me know if you have any trouble Happy driving!

info@magicdrillpress.com